

(c) Vette Antennelag. 2011


Mulig løsning problemer med trådløs forstyrret av naboens ruter.

Logg deg på ruterer ved å gå til ruterer sin hjemmeside på:

<http://192.168.0.1/>

Du skal få opp følgende side:

Product Page: DIR-635 Hardware Version: B3 Firmware Version: 2.33EU



LOGIN

Log in to the router:

User Name : Admin

Password :

Log In

English

WIRELESS

Har du ikke endret passord mener jeg å huske at default passord er blank. Sjekk evt brukerveiledningen for ruterer for å finne default passord.

Når du har logget på velg «SETUP» i toppmenyen og «WIRELESS SETTINGS» i venstre menyen, når siden kommer opp klikk på «Manual wireless network setup»

Product Page: DIR-635 Hardware Version: B3 Firmware Version: 2.33EU

The screenshot shows the D-Link DIR-635 web interface. At the top, there is a navigation bar with the D-Link logo and a menu with options: DIR-635, SETUP, ADVANCED, TOOLS, STATUS, and SUPPORT. The 'SETUP' option is highlighted with a red box. Below this, a sidebar on the left contains a menu with options: INTERNET, WIRELESS SETTINGS, NETWORK SETTINGS, and USB SETTINGS. The 'WIRELESS SETTINGS' option is also highlighted with a red box. The main content area is titled 'WIRELESS SETTINGS' and contains three sections: 'WIRELESS NETWORK SETUP WIZARD', 'ADD WIRELESS DEVICE WITH WPS (WI-FI PROTECTED SETUP) WIZARD', and 'MANUAL WIRELESS NETWORK SETUP'. The 'MANUAL WIRELESS NETWORK SETUP' section is highlighted with a red box. On the right side of the interface, there is a 'Helpful Hints...' section with text providing instructions on how to use the wireless setup wizards.

WIRELESS SETTINGS

The following Web-based wizards are designed to assist you in your wireless network setup and wireless device connection.

Before launching these wizards, please make sure you have followed all steps outlined in the Quick Installation Guide included in the package.

WIRELESS NETWORK SETUP WIZARD

This wizard is designed to assist you in your wireless network setup. It will guide you through step-by-step instructions on how to set up your wireless network and how to make it secure.

[Wireless Network Setup Wizard](#)

Note: Some changes made using this Setup Wizard may require you to change some settings on your wireless client adapters so they can still connect to the D-Link Router.

ADD WIRELESS DEVICE WITH WPS (WI-FI PROTECTED SETUP) WIZARD

This wizard is designed to assist you in connecting your wireless device to your wireless router. It will guide you through step-by-step instructions on how to get your wireless device connected. Click the button below to begin.

[Add Wireless Device with WPS](#)

MANUAL WIRELESS NETWORK SETUP

If your wireless network is already set up with Wi-Fi Protected Setup, manual configuration of the wireless network will destroy the existing wireless network. If you would like to configure the wireless settings of your new D-Link Systems Router manually, then click on the Manual Wireless Network Setup button below.

[Manual Wireless Network Setup](#)

Helpful Hints...

If you already have a wireless network setup with Wi-Fi Protected Setup, click on **Add Wireless Device Wizard** to add new device to your wireless network.

If you are new to wireless networking and have never configured a wireless router before, click on **Wireless Network Setup Wizard** and the router will guide you through a few simple steps to get your wireless network up and running.

If you consider yourself an advanced user and have configured a wireless router before, click **Manual Wireless Network Setup** to input all the settings manually.

[More...](#)

(c) Vette Antennelag. 2011

Du får da opp følgende side, velg en annen kanal en den du har valgt i dag.

Save settings. Forsøk evt andre kanaler for å finne en som naboen ikke har. Rekkevidden er begrenset så etter noen forsøk bør man finne en som virker. Større hopp i kanal gir større hopp i frekvens.

Product Page: DIR-635 Hardware Version: B3 Firmware Version: 2.33EU

D-Link

DIR-635 // SETUP ADVANCED TOOLS STATUS SUPPORT

INTERNET WIRELESS SETTINGS NETWORK SETTINGS USB SETTINGS English

WIRELESS

Use this section to configure the wireless settings for your D-Link Router. Please note that changes made on this section may also need to be duplicated on your Wireless Client.

Save Settings Don't Save Settings

WIRELESS NETWORK SETTINGS

Enable Wireless : Always New Schedule

Wireless Network Name : GET76975PRIVAT (Also called the SSID)

802.11 Mode : Mixed 802.11n, 802.11g and 802.11b

Enable Auto Channel Scan :

Wireless Channel : 2.437 GHz - CH 6

Transmission Rate : (Mbit/s)

Channel Width :

Visibility Status :

WIRELESS SECURITY MODE

To protect your privacy you can configure wireless security modes, including WEP, WPA and WPA-Enterprise. WEP is the original wireless encryption standard. WPA provides a higher level of security. WPA-Enterprise does not require an authentication server. The WPA-Enterprise option requires an external RADIUS server.

Security Mode : WPA-Personal

Helpful Hints... Changing your Wireless Network Name is the first step in securing your wireless network. Change it to a familiar name that does not contain any personal information. Enable Auto Channel Scan the router can select the best possible channel for your wireless network to operate on. Enabling Hidden Mode is another way to secure your network. With this option enabled, no wireless clients will be able to see your wireless network when they scan to see what's available. For your wireless devices to connect to your router, you will need to manually enter the Wireless Network Name on each device. If you have enabled Wireless Security, make sure you write down the Key or Passphrase that you have configured. You will need to enter this information on any wireless device that you connect to your wireless network.